

Driver Installation

After downloading the driver you should unzip the files into a temporary folder. The method of installing the software varies between versions of Windows but essentially, when you plug the GPS Display into an USB port the operating system will prompt for a driver. You should then point it to the temporary folder and install from there.

If, for some reason, you are not prompted to install the driver you can navigate to Device Manager and you should see an entry under Other Devices called “SC GPS Display”. Right click on that and select Update Driver Software. You can then direct the operating system to the temporary folder.

After you have successfully installed the driver you should see the GPS Display listed in Device Manager under Ports (COM and LPT) as “Communications Port - Silicon Chip USB Serial Port”. Take note of the COM port number allocated by the operating system, you will need this when configuring software to work with the GPS Display.

