



**ELECTRET  
MICROPHONE  
INPUT**

**EXTERNAL  
TRIGGER  
CONTACTS (NO)**



**CAMERA  
SHUTTER  
RELEASE**

**DELAYED  
FLASH  
TRIGGER OUT**



**ELECTRET  
SENSITIVITY**



**PRESS  
TO ARM**



**TRIGGERED**



**READY**



DELAY TIME (UNITS = 1ms OR 10ms)

<p><b>HUNDREDS</b></p>	<p><b>TENS</b></p>	<p><b>UNITS</b></p>	<p><b>1ms</b></p> <p><b>10ms</b></p> <p><b>DELAY UNITS</b></p>
------------------------	--------------------	---------------------	--

**SILICON  
CHIP** [www.siliconchip.com.au](http://www.siliconchip.com.au)



**POWER**



**TIME DELAY PHOTOFLASH TRIGGER**

